


# TR FLEX® RESTRAINED JOINT PIPE

## For Generations



Pipe Size In.	*Pressure Rating psi	Α	В	C	# of D.I.	# of	Max	
		In.	PIPE In.	In.	Locking Segments	Rubber Segments Retainers	Deflection Degrees	Pullout
4	350	4.80	7.25	4.84	2	1	5	0.03
6	350	6.90	9.52	5.27	2	1	5	0.04
8	350	9.05	11.93	5.82	2	1	5	0.04
10	350	11.10	14.37	6.03	2	1	5	0.05
12	350	13.20	16.68	6.30	4	2	5	0.06
14	350	15.30	19.16	7.75	4	2	3-1/4	0.05
16	350	17.40	21.46	7.95	4	2	3-1/4	0.05
18	350	19.50	23.76	8.19	4	2	3	0.05
20	350	21.60	26.04	8.40	4	2	2-1/2	0.05
24	350	25.80	30.61	8.86	8	4	2-1/4	0.05
30	250	32.00	36.88	10.28	8	4	1-3/4	0.05
36	250	38.30	43.85	10.87	8	4	1-1/2	0.05

<sup>\*</sup>The TR FLEX® Restrained Joint has a working pressure rating equivalent to the working pressure rating of the parent pipe with a maximum working pressure rating of 350 psi for 4 in. through 24 in. and 250 psi for 30 in. through 36 in.

NOTE: These deflections are based on joints with nominal dimensions.

#### **ASSEMBLY INSTRUCTIONS**

- Step 1. (4''-10'') Lay pipe such that one of the bell slots is accessible. (12"-20") Lay pipe such that both of the bell slots are accessible, in the horizontal position if possible. (24"-36") Lay pipe such that all four of the bell slots are accessible, in the diagonal position if possible.
- Clean the bell socket and insert gasket.
- Clean the spigot end to the assembly stripes. Step 3.
- Lubricate the exposed surface of the gasket and pipe spigot end back to the weld bead.
- Step 5. Make a normal push-on joint assembly, completely homing the pipe until the first assembly strip is in the bell socket. Keeping the joint in straight alignment during the assembly process.
- (4"-10") Insert the right-hand locking segment into a bell slot and slide the segment clockwise around the pipe. (12"-36") Insert lower locking segment into a bell slot and slide the segment around the pipe.
- (4"-10") Insert left-hand locking segment into the bell slot and slide the segment counter-clockwise around the pipe. (12"-36") Insert upper locking segment into the same bell slot and rotate around the pipe.
- (4"-10") Hold the segments apart and wedge the rubber retainer into the slot between the two locking segments. (12"-36") Hold the upper segment in place and wedge the rubber retainer into the slot between the two locking segments.
- Step 9. (4"-10") None. (12"-20") Repeat steps 6-8 for other slot. Make sure that all 4 locking segments and 2 rubber retainers are securely in place. (24"-36") Repeat steps 6-8 for other slot. Make sure that all 8 locking segments and 4 rubber retainers are securely in place.
- Step 10. Extend the joint to remove the slack in the locking segment cavity. Joint extension is necessary to attain the marked laying length on the pipe and to minimize growth or extension of the line as it is pressurized.
- Step 11. Set the joint deflection as required.



### **IRON STRONG**



OHIO 2266 S. 6th St. Coshocton, OH 43812 740-622-6651 mcwaneductile.com

UTAH 1401 E 2000 S. Provo, UT 84603 mcwaneductile.com



1757 Burlington St. E Hamilton, ON L8N-3R5 905-547-3251 canadapipe.com















